

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:

Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2
Ulster Park, NY 12487
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468

www.CommunityPlaythings.com
Sales@CommunityPlaythings.com



A276 Cubby Corner Shelf

Recommended Use

The Cubby Corner Shelf can be used to create a smooth 90° corner in a line of Cubbies. It can also end a line of Cubbies.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only. This Corner Shelf is not waterproof.

Assembly

Your Cubby Corner Shelf comes in one carton containing:

1. One Cubby Corner Shelf.
1. Hardware for mounting.
2. This Product Guide.

If your shipment is incomplete, please contact Customer Service.

Installation Instructions

This item should be fastened securely to the wall or floor, or securely fastened to another Community Cubby that is fastened to the wall or floor. Enclosed for that purpose are:

1. Four ¾" x #8 oval head screws.
2. Four 1½" x #8 oval head screws.
3. Two 2" corner braces.

The ¾" screws are for the side or top of the Corner Shelf. The 1½" screws are for the wall or floor, but if not suited to the building construction, fasteners appropriate to the construction must be used.

⚠ WARNING

- ▲ Any Cubby configuration must be installed by a competent carpenter or maintenance person to ensure stability. The customer assumes full responsibility that the Cubby(s) will be secure for the long term.

Plastic Connectors

Push sides of units together, then pull from front on one unit to check connection. Cubby units can be disconnected by pulling units apart with a quick, firm pull. A clacking noise is normal during disconnection.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning

Wipe with a damp cloth and mild detergent. Do not use excessive water.

Construction

The wooden components are manufactured from solid hardwood and hardwood plywood, with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning.

Packaging Recycling

All our packaging is recyclable in two simple categories:

Packaging Materials	Recycling Category
Cardboard boxes and pads, newsprint	corrugated cardboard
Plastic wrap, sheet foam, foam pads	Plastic #4 LDPE

Please help us preserve the earth for the children and recycle at an appropriate facility.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.



Use only replacement parts supplied by Community Playthings.