

Product Guide

User and Maintenance Information

Important Information:
Please save this product guide.

G471, G472, G474 Unit Blocks

Recommended Use

Unit blocks are a popular means of learning. They are a medium for expressing rhythm, pattern and design and are one of the best instructional playthings. Children love the feel of the smooth, rounded wood, and never tire of the endless variety of constructions they can create.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only, water and dirt will spoil these blocks.

Assembly

No assembly is required. Please note:

- G471 carton contains 48 Units
- G472 carton contains 24 Doubles
- G474 carton contains 12 Quads

If your shipment is incomplete, please call Customer Service.

Cleaning

If your blocks become dirty, you may want to wash them. If so, use a minimum of soap and water. Too much water may cause warping or rotting.

If washing doesn't remove enough dirt from your blocks, try *lightly* sanding them. Blocks won't stack well if heavily sanded.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Construction

Blocks have rounded corners and are manufactured from solid maple.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed.

Use only replacement parts supplied by Community Playthings.

Customer Service:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com

