

# Product Guide

## User and Maintenance Information

**IMPORTANT INFORMATION:** Please save this product guide.

## W441 Streambed and Outlast Flow Pan

### Recommended Use

The Outlast Streambed introduces running water into your outdoor play area. Contoured trays on three levels with outflow allow water (or natural, loose parts) to flow down. The Flow Pan adds additional water storage with a child friendly rubber plug. The Streambed provides a transition between high and low tables in a variety of configurations but is designed to empty only into the 18" Table.

### ⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.
- ▲ Water is a drowning hazard. Do not leave pan of water unattended.

### ⚠ CAUTION

- ▲ Adults are responsible to prevent Outlast Tables from being employed by children in unsafe combinations with other components.

### Assembly

Your Streambed comes fully assembled and ready to use. Inside the carton are:

- 1 Streambed with three contoured trays.
- 2 One Flow Pan.
- 3 This product guide.

**If your shipment is incomplete, please call Customer Service.**

### Accessories

**Flow Pan** adds an extra level and water flow possibilities

### Maintenance

Acetylated wood weathers a natural silver grey if left untreated outdoors.

If you prefer the original look, scrub with a bleach or detergent solution. When dry, apply a tinted, nontoxic penetrating stain, then apply a nontoxic mildewcide to minimize mildew growth.

Periodically inspect for splinters, broken or loose parts, and/or malfunctions. Remove from service when any condition develops that might make operation unsafe.

### Cleaning

Mud and dirt can be removed with scrub brush and water. Over time outdoors, surfaces may blacken with mildew. Remove with detergent or a bleach solution. Trays can be removed for cleaning.



### Construction

The wooden components are manufactured from long lasting acetylated wood and finished with a water based stain. All edges and corners are rounded for safety and ease of cleaning.

End grain is protected by plastic guards. Stainless steel hardware is used throughout and plastic components are formulated to ensure long life in outdoor environments.

### User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

### Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

**Use only replacement parts supplied by Community Playthings.**



### CUSTOMER SERVICE:

#### United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com

