

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

C221 Square Woodcrest Table C231 Round Woodcrest Table C241 Rectangular Woodcrest Table

Recommended Use

Designed to support the dramatic play needs of children. Children may wish to use the Woodcrest Tables for "playing house."

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement. Therefore supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only. This table is not waterproof.

Assembly

This product comes in two cartons:

- The carton marked C229, C239, or C249 contains this product guide and one Table top.
- The second carton contains four legs and instructions for assembly.

If your shipment is incomplete, please call Customer Service.

Maintenance

Periodically inspect for cracks, breaks, loose parts, or missing parts. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning

Clean with warm water and a mild household detergent. Too much water may harm the finish of the wooden top. To disinfect this product, a mild bleach solution may be used.

Construction

This product is made from solid maple, with a clear nontoxic finish. The edges and corners are rounded for safety and ease of cleaning. Plastic Sockets are constructed from polypropylene.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com

