

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com



C140 Playsize Cradle

Recommended Use

The Playsize Cradle is simple, graceful, and strong. Ideal for creative and dramatic play. Recommended for children between the ages of 2 to 8.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement therefore supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only, this Playsize Cradle is not waterproof.

Assembly


Your Playsize Cradle comes in one carton. Inside are:

1. One Playsize Cradle.
2. This product guide.

If your shipment is incomplete, please contact Customer Service.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.



Cleaning

Wipe the wood parts with a damp cloth and a mild detergent. Do not use excessive water.

Construction

The wooden components are manufactured from durable birch plywood or solid maple with a clear nontoxic finish.

Packaging Recycling

Please help preserve the earth for the children and recycle at an appropriate facility.

All our packaging is recyclable in two simple categories:

Packaging Materials	Recycling Category
Cardboard boxes and pads, newsprint	corrugated cardboard
Plastic wrap, sheet foam, foam pads	Plastic #4 LDPE

User modifications

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.