

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2
Ulster Park, NY 12487
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468

www.CommunityPlaythings.com
Sales@CommunityPlaythings.com



A240/A241 Infant Cubby 4 A242/A243 Infant Cubby 2

Recommended Use

The Infant Cubby is designed for wall storage of infants' clothing and other accessories. The parent-teacher communication pocket on the door will hold a clipboard or single subject notebook. A sturdy double coat hook is provided for jackets or bags. The top shelf fits a Community Tote or Basket.

⚠ CAUTION

- ▲ For indoor use only. The Infant Cubby is not waterproof.
- ▲ This product is intended for use in caring for children of immature judgement. Therefore supervision is required at all times.

Assembly

Your Infant Cubby comes in one carton containing:

1. One Infant Cubby.
2. This Product Guide.

Baskets, if ordered, ship in a separate carton.

If your shipment is incomplete, please contact Customer Service.

Installation

Installation requires a competent carpenter or maintenance person.

1. Position Infant Cubby at the desired place on the wall.
2. Locate the fasteners (not included) to suit the wall construction, with at least one fastener near each end of the cleat.
3. Predrill the cleat at these locations.
4. Attach the Infant Cubby to the wall with fasteners appropriate to the wall construction and the weight of the fully loaded unit.



⚠ WARNING

- ▲ The Infant Cubby must be properly mounted before use. The customer must assume full responsibility that it will be secure for the long term.

Accessories

Tote Boxes and Baskets come with a clear label holder to protect a paper label at the front of each box.

Operation

The doors have a child proof lock to allow for storage of items that should be inaccessible to children. The lock is operated by turning the latch 90°. A plastic key is provided for this, although any key, coin, or similar object will work as well.

Maintenance

Periodically inspect for secure connections, cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning

Wipe with a damp cloth and mild detergent. Do not use excessive water. Baskets are machine washable.

Construction

The wooden components are manufactured from solid hardwood, with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning. All plastic parts are engineered for durability. Baskets and Totes are made of polypropylene.

Packaging Recycling

Please help us preserve the earth for the children and recycle at an appropriate facility.

All our packaging is recyclable in two simple categories:

Packaging Materials	Recycling Category
Cardboard boxes and pads, newsprint	corrugated cardboard
Plastic wrap, sheet foam, foam pads	Plastic #4 LDPE

Page 2

User and Maintenance Information (cont'd)

User Modifications

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com

