

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

Recommended Use

The Community Playthings Teacher's Low Chair is designed to give the teacher a comfortable seat at the interaction level of infants, toddlers, and young children. This 12" chair has enough seat width and back support for the average adult.

Move the chair easily using the handhold opening.



⚠ WARNING

- ▲ Maximum working load: 375 lb.

⚠ CAUTION

- ▲ For indoor use only. This chair is not waterproof.

J432 Teacher's Low Chair

Maintenance

Periodically inspect chair for splinters or breakage. Remove the product from use when any condition develops that might make use unsafe.

Cleaning

Wipe the chair with a damp cloth and a mild detergent. Do not use excessive water.

Refinishing

Like other Community Playthings products, this Teacher's Low Chair can easily be refinished. Sand or strip off the old finish, and apply one or two coats of clear finish. Be sure to check your finish for the label "safe for children's toys".

Construction

Chair is laminated from hard maple veneer and finished with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning. Boots are molded from durable elastomer.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, please contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com

