

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com



P531 High Chair Footrest

Recommended Use

Your High Chair Footrest is designed to be used with the P53 High Chair, and is recommended for children age 6 months to 24 months.



⚠ WARNING

- ▲ Always keep child in view while in High Chair.
- ▲ Never leave child unattended.
- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

- ▲ For indoor use only. The High Chair Footrest is not waterproof.

Assembly

The carton you receive contains:

1. One High Chair Footrest.
2. This product guide.
3. Package of four 25mm screws.
4. 1 T20 hand screw driver and 1 T20 insert bit

If this shipment is incomplete, please call Customer Service.

This High Chair Footrest is made to fit on the P53 High Chair giving two height positions for the user's feet. Attach the Footrest to backside of front apron of chair using the 4 screws provided. The six pre-drilled screw holes in back of front apron give two possible heights.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove from service when any condition develops that might make operation unsafe.

Cleaning

Wipe wood with a damp cloth and a mild detergent or disinfectant. Do not use excessive water. Avoid abrasive cleaners, aromatic spirits, and cleaning solutions containing pine oil (such as Lysol) for cleaning. Disinfectants can be used, but no solvents.

Construction

The wooden components are manufactured from solid maple and birch plywood.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.