

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

Recommended Use

The A14 Storage Chest is a handy storage unit for blocks or other small items, which moves easily on heavy duty casters. The A141 Block Trays stack onto the storage chest for additional storage space.

▲ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.
- ▲ Stack no more than two A141 Block Trays on top of A14 Storage Chest.

▲ CAUTION

For indoor use only. The Storage Chest and Block Tray are not waterproof.

Assembly

If you ordered the storage chest there will be a lid included in the same carton.

If your shipment is incomplete, please contact Customer Service.

A14 Storage Chest A141 Block Tray

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning

Wipe the wood parts with a damp cloth and a mild detergent. Do not use excessive water.

Construction

The wooden components are manufactured from durable plywood or solid maple and finished with a clear nontoxic finish. The casters are made of plated steel with non-marking nylon wheels that swivel on ball bearings.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com

