

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

Recommended Use

Place gate at bottom of Loft stair to restrict access to the Loft.

The counter top encourages dramatic play.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgment; therefore supervision is required at all times
- ▲ This accessory is intended for use only on the Community Playthings Loft.

⚠ CAUTION

- ▲ Make sure all four corners are engaged.


Assembly

The Loft Gate comes in a single carton.

If your shipment is incomplete, please call Customer Service.

Operation

Place bottom rail into connectors at the bottom of Loft stair. Push top rail forward into top connectors until latches engage.



It may be necessary to pull posts laterally towards center of the gate (see arrows) to induce latching.

To remove gate, pull triggers under top rail towards center and swing out.

L137 Loft Gate

Storage

Store the gate in front of any single size panel on the lower level of the Loft.

Cleaning

Wooden parts may be wiped with a damp cloth.

Maintenance

Periodically inspect for cracks, breaks, loose parts and/or malfunctions. Remove the product from service when any condition develops which might make operation unsafe.

Construction

The rounded solid maple frame is finished with a clear nontoxic finish.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com

