

# Product Guide

## User and Maintenance Information

**IMPORTANT INFORMATION:**  
Please save this product guide.

### CUSTOMER SERVICE:

#### United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com




# J413 Chair Dolly

## Recommended Use

The Chair Dolly has been designed to store Community Playthings Childshape and Mealtime Chairs.

### ⚠ WARNING

- ▲ This accessory is intended for use with the following Community Playthings products only:  
J206, J208, J210, J212, J408, J410, J412 Childshape Chairs.  
J421, J422, J423, J424, J441, J442, J443, J444, J806, J807, J808, J809, J810, J811, Mealtime Chairs.
- ▲ This product is intended for use by children of immature judgement therefore supervision is required at all times.
- ▲ Never have a Chair with a child in it on the Chair Dolly. Never stack more than 5 high due to instability.



## Assembly

Equipment comes in a single carton.

The carton contains:

1. Your Chair Dolly.
2. This product guide.

**If your shipment is incomplete, please contact Customer Service.**

## Operation

Before using this product familiarize yourself with the foot operated caster locks and how to lock and unlock them.

Brace the Chair Dolly against a wall and lock all four casters with the step on levers.

Place the rear legs of the Chair between the dowels on the Dolly.

Always lock the casters after the Chair Dolly has been moved. Store the Chair Dolly upright, against a wall, or in a closet where it will not be tripped over.

This Chair Dolly is not designed for use on deep carpet, rough floors or out of doors.

## Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

## Cleaning

Wipe the wooden parts with a damp cloth and a mild detergent (or a mild disinfectant). Do not use excessive water.

## Construction

The wooden components are manufactured from durable hardwood plywood or solid maple and finished with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning.

The casters are made of plated steel with non-marking rubber wheels that swivel on ball bearings.

## User Modifications

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

## Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

**Use only replacement parts supplied by Community Playthings.**