

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:
Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com



Recommended Use

The storage dresser is for storing clothing, blankets, and accessories in the early childhood environment.

⚠ WARNING

▲ This product is intended for use around children of immature judgment, therefore supervision is required at all times.

▲ Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Always secure dresser to a solid wall using the provided restraint strap.
- Place heaviest items in the lowest drawers.
- Do not set TV's or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers.
- Never open more than one drawer at a time.
- Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.

▲ Installation requires a competent carpenter or maintenance person to secure dresser to wall with restraint strap provided.

▲ Do not use as a changing table.

⚠ CAUTION

▲ Use caution when opening and shutting drawers with small children near by.

Assembly

Your dresser comes to you completely assembled in one carton containing:

1. One Storage Dresser
2. One restraint strap kit.
3. This product guide.

If your shipment is incomplete, please call Customer Service.

Operation

Drawers have a soft, self-closing feature that prevents slamming. Push drawer shut until the soft close engages.

Maintenance

Periodically inspect for cracks, breaks, loose parts, loose screws, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

G230 Storage Dresser

Cleaning

Wipe with damp cloth and a mild detergent. Do not use excessive water.

Construction

Wooden components are manufactured from solid maple and poplar, durable plywood, and finished with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning. Handles are durable, engineered plastic. Drawer slides are top quality furniture grade.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

