

# Product Guide

## User and Maintenance Information

**IMPORTANT INFORMATION:**  
Please save this product guide.

### Recommended Use

The Peg Tree provides hanging space for aprons, dress-ups, hats, bags and extra clothing for children 2 to 8 years old.

#### **WARNING**

▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

#### **CAUTION**

▲ For indoor use only. The Peg Tree is not waterproof.

### Assembly

The Peg Tree comes in 2 parts (see figure A): the Stand and the Post. To assemble the Peg Tree, refer to the following steps:

1. Insert the slotted end of the Post into the Stand
2. Tap the Stand and Post on the floor
3. Ensure that the Post is firmly engaged into the Stand.

**If your shipment is incomplete, please call Customer Service.**

### Maintenance

Periodically inspect for cracks, breaks, and loose or missing parts. Remove product from service when any condition develops that might make operation unsafe.

### Cleaning

Clean the Peg Tree with a mild detergent & water. Too much water will harm the finish on the wood.

## H559 Peg Tree H569 Toddler Peg Tree




Figure A

### Construction

The wooden components are manufactured from solid maple and hardwood plywood, and are protected with a clear nontoxic finish.

### User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

### Ordering Parts

To order replacement parts, contact your Customer Center with a description of the part(s) needed and the ID Code from the product.

**Use only replacement parts supplied by Community Playthings.**

### CUSTOMER SERVICE:

#### United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

[www.CommunityPlaythings.com](http://www.CommunityPlaythings.com)

[Sales@CommunityPlaythings.com](mailto:Sales@CommunityPlaythings.com)

