# W482 **Outlast Tunnel** W483 **Outlast Bridge**

User and Maintenance Information

Guide

Product

#### IMPORTANT INFORMATION: Please save this product guide.

## **Recommended Use**

The Outlast Bridge and Tunnel provide a range of large muscle and exploratory play opportunities for crawlers and beginning walkers. Items should be placed on a flat non-abrasive surface. The tunnel windows allow supervision as well as being peep holes for children. Bridge railings are just the right height for cruisers, allowing them to navigate the gentle curve.

For ages 9-36 months

## **WARNING**

- This product is intended for use by children of immature judgment and therefore adult supervision is required at all times.
- ▲ Fall Hazard! Top of tunnel is not a play surface. Do not climb on top of tunnel.
- ▲ Prevent injury. Maintain a clear use zone of at least 36" around product.

#### Maintenance

Acetylated wood weathers a natural silver-gray if left untreated, outdoors. If you prefer the original look, scrub with a bleach or detergent solution. When dry, apply a tinted, nontoxic penetrating stain, then apply a nontoxic mildewcide to minimize mildew growth. Periodically inspect for splinters, broken or loose parts, and/or malfunctions. Remove from service when any condition develops that might make operation unsafe.

#### Cleaning

Mud and dirt can be removed with scrub brush and water. Over time in outdoor settings surface may blacken with mildew. A bleach solution or safe detergent can be used to remove blackness.

## Construction

The wooden components are manufactured from long lasting acetylated wood and finished with a tinted nontoxic stain. All edges and corners are rounded for safety and ease of cleaning.

Stainless steel hardware is used throughout and plastic components are formulated to ensure long life in outdoor environments.

#### **User Modifications**

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

## **Ordering Parts**

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID code from the product.

#### Use only replacement parts supplied by Community Playthings.





#### CUSTOMER SERVICE:

United States PO Box 2 Ulster Park, NY 12487 Office hours: 9-5 EST Phone (800) 777-4244 Fax (800) 336-5948 (845) 572-3468 www.CommunityPlaythings.com Sales@CommunityPlaythings.com



© 2019 by Community Products, LLC FZ25 DC 6819 Revision A