

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION:

Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2
Ulster Park, NY 12487
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468

www.CommunityPlaythings.com
Sales@CommunityPlaythings.com



W460 Outlast Arbor W461 Outlast Canopy Support W462 Outlast Canopy

Recommended Use

The Outlast Arbor provides an instant nook or cozy corner anywhere in your yard. Move the two Canopy Supports into place, and drape the Outlast Canopy over them to create a protected, yet fully supervise-able, nook.

The canopy fabric hooks onto small buttons on the Canopy Support corners. The sturdy base provides seating, a work surface, and storage.

The Canopy adds a touch of atmosphere to your yard and is not intended as a shade cloth.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement. Supervision is required at all times.
- ▲ To prevent falls or tip over injuries, do not allow children to pull or climb on canopy.
- ▲ To prevent entrapment or strangulation, avoid creating loops or openings when fastening canopy.

⚠ CAUTION

- ▲ Adults are responsible to prevent Outlast Mud Kitchen items from being employed by children in unsafe combinations with other components.

Maintenance

Acetylated wood weathers a natural silver grey if left untreated outdoors. If you prefer the original look, scrub with a bleach or detergent solution. When dry, apply a tinted, nontoxic penetrating stain, then apply a nontoxic mildewcide to minimize mildew growth. Periodically inspect for splinters, broken or loose parts, and/or malfunctions. Remove from service when any condition develops that might make operation unsafe.

Cleaning

Mud and dirt can be removed with scrub brush and water. Over time outdoors, surfaces may blacken with mildew. Remove with detergent or a bleach solution.

The Canopy can be washed with mild soap or detergent and water.

Construction

The wooden components are manufactured from long lasting acetylated wood and finished with a water based stain. All edges and corners are rounded for safety and ease of cleaning. End grain is protected by plastic guards. Stainless steel hardware is used throughout and plastic components are formulated to ensure long life in outdoor environments. The Canopy is made of UV-stabilized polyester fabric.

User Modifications

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

If your shipment is incomplete, please call Customer Service.

