Product Guide

User and Maintenance Information

IMPORTANT INFORMATION: Please save this product guide.

CUSTOMER SERVICE:

United States PO Box 2 Ulster Park, NY 12487 Office hours: 9-5 EST Phone (800) 777-4244 Fax (800) 336-5948 (845) 572-3468 www.CommunityPlaythings.com Sales@CommunityPlaythings.com



© 1993 by Community Products, LLC MN26 DC 749 Revision P

J800 Child's Rocking Chair 10"

Recommended Use

This solid maple rocking chair is designed for general classroom or home use. We recommend the following age range: 3-5 years.

A WARNING

This chair is intended for use by children of immature judgement therefore supervision is required at all times.

A CAUTION

▲ For indoor use only, this chair is not waterproof.

Assembly

Your rocking chair comes completely assembled and ready to use. Inside are:

- 1. Your assembled chair.
- 2. This product guide.

If your shipment is incomplete, please call Customer Service.

Maintenance

Periodically inspect for cracks, breaks, loose parts, loose screws, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make use unsafe.

Cleaning

Wipe with a damp cloth and a mild detergent. Do not use excessive water.

Construction

The wooden components are manufactured from solid maple and finished with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning.

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

