G231 Toddler Step Stool

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION: Please save this product guide.

Recommended Use

Your Toddler Step Stool enables children 12-24 months to reach an adult height sink or counter with adult supervision. The gate is to prevent toddlers from climbing the steps when unsupervised. The gate is made to stow away under the bottom stair tread when not in use. These steps are designed for stationary use.

A WARNING

This product is intended for use by children of immature judgement; therefore, supervision is required at all times.

A CAUTION

- ▲ Make sure that the gate is fully latched in one of the two latchable positions. The gate is not to be used in any other position.
- ▲ Keep the stair tread dry to protect the child from the risk of slipping.

Assembly

Your Toddler Step Stool comes fully assembled. The gate is stowed beneath the bottom stair tread.

If your shipment is incomplete, please call Customer Service.

Operation

To open or close the child-safe gate, pull both yellow latches toward the center at same time.

Maintenance

Regular wiping of step stool will keep it in good condition. Periodically inspect for secure connections, cracks, breaks, loose parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Cleaning

Wipe with a damp cloth and mild detergent. Do not use excessive water.

Construction

Your Step Stool is built with solid maple and hardwood plywood using mortise and tenoned joints. Routered hand holds in the sides provide more grip.

Packaging Recycling

Please help preserve the earth for the children and recycle at an appropriate facility.

All our packaging is recyclable in two simple categories:

Packaging Materials	Recycling Category
Cardboard boxes and pads, newsprint	corrugated cardboard
Plastic wrap, sheet foam, foam pads	Plastic #4 LDPE

User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.



CUSTOMER SERVICE:

United States PO Box 2 Ulster Park, NY 12487 Office hours: 9-5 EST Phone (800) 777-4244 Fax (800) 336-5948 (845) 572-3468 www.CommunityPlaythings.com Sales@CommunityPlaythings.com



© 1993 by Community Products, LLC XU69 DC 6742 Revision C